

# ***Kenworth***

***CAB & SLEEPER PANELS***

## ***W900L - T800***



***CAB PANELS***

***SLEEPER PANELS***

***HOOD REPLACEMENT PANELS***

***EXTENSION PANELS***



### CAB PANELS



**VK110200**  
W900L - AEROCAB - SLEEPER  
PANELS - 50.25" - BLANK



**VK110201**  
T660 - CAB PANELS - BLANK


**USE THE BLANK CAB PANELS FOR YOUR CAB PANEL LIGHT OPTIONS**



**EXAMPLE**  
VK110200-4UN



**EXAMPLE**  
VK110200-5R



**EXAMPLE**  
VK110200-4RA



**EXAMPLE**  
VK110200-5TL



**EXAMPLE**  
VK110200-4EA

#### TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 162)
- 3 - PICK THE NUMBER OF LIGHTS

#### EXAMPLE:

**VK110200 - CAB PANEL - BLANK**

**4 - NUMBER OF LIGHTS**

**E - ELITE (A - AMBER)**

**VK110200 - 4 EA**



### SLEEPER PANELS



#### VK142035

KW SLEEPER PANELS - T600  
(1995 & NEWER, NO FAIRINGS  
) T800 ( 1986 & NEWER ), W900  
(1986 & NEWER ) - 42" - BLANK



#### VK142008

KW SLEEPER PANELS -  
AEROCAB - NO SIDE FAIRING -  
T600, T800, W900 - 60" - BLANK  
- 1995 & NEWER



#### VK142015

KW SLEEPER PANELS -  
AEROCAB - NO SIDE FAIRING -  
T600, T800, W900 - 72" - BLANK



#### VK142023

KW SLEEPER PANELS -  
AEROCAB - NO SIDE FAIRING  
- T600, T800, W900 - 86" -  
BLANK



#### VK142030

KW SLEEPER PANELS -  
AEROCAB - NO SIDE FAIRING  
- T600, T800, W900 - 62"  
- BLANK



#### VK142100

KW SLEEPER PANELS -  
AEROCAB - W/EXHAUST  
- W900 L - 62" - BLANK



#### VK142101

KW SLEEPER PANELS -  
AEROCAB - W/EXHAUST  
- W900 L - 72" - BLANK



#### VK142105

KW SLEEPER PANELS -  
AEROCAB - W/FUEL DOOR -  
W900 L - 86" - BLANK

**USE THE BLANK SLEEPER PANELS FOR  
YOUR SLEEPER PANEL LIGHT OPTIONS.**



**EXAMPLE**  
VK142008-3UN



**EXAMPLE**  
VK142008-5RA



**EXAMPLE**  
VK142015-7TL



**EXAMPLE**  
VK142023-8EA

#### TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 162)
- 3 - PICK THE NUMBER OF LIGHTS

#### EXAMPLE:

**VK112023 - SLEEPER PANEL - BLANK**

**8 - NUMBER OF LIGHTS**

**E - ELITE (A - AMBER)**

**VK112023 - 8 EA**



### HOOD EXTENSION PANELS



**VK110300**

HOOD EXTENSION PANELS - W900L - BLANK - 1997-2004

**USE THE BLANK PANELS FOR YOUR EXTENSION PANEL LIGHT OPTIONS**

**EXAMPLE**



**VK110300-3UN**

**EXAMPLE**



**VK110300-4EA**

**EXAMPLE**



**VK110300-4TL**

#### TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 162)
- 3 - PICK THE NUMBER OF LIGHTS

**EXAMPLE:**

**VK110300 - HOOD EXTENSION - BLANK**

**4 - NUMBER OF LIGHTS**

**TL - TUNNEL LIGHT**

**VK110300 - 4 TL**



### SLEEPER EXTENSION PANELS



**VK143001**

SLEEPER EXTENSION PANELS  
- T600, T800, W900 - BLANK -  
1992 & NEWER

**USE BLANK EXTENSION PANELS FOR  
YOUR EXTENSION LIGHT OPTIONS**



**EXAMPLE**

VK143001-1TL



**EXAMPLE**

VK143001-1EA



**EXAMPLE**

VK143001-2RA



**EXAMPLE**

VK143001-2RN

#### TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 162)
- 3 - PICK THE NUMBER OF LIGHTS

**EXAMPLE:**

**VK143001 - SLEEPER EXT. PANEL - BLANK**

**1 - NUMBER OF LIGHTS**

**E - ELITE (A - AMBER)**

**VK143001 - 1 EA**



### LIGHT OPTION CHART

USE THE FOLLOWING LIGHT CHART TO BUILD YOUR REAR LIGHT BARS, CAB AND SLEEPER PANELS, HOOD EXTENSION PANELS, AND SO ON. USE THE FIRST LETTER IN THE NAME OF THE LIGHT AND THE FORM YOU WISH THE LIGHT TO BE.

### EXAMPLE

XXXXXXXX  
PART NUMBER

X  
NUMBER OF LIGHTS

E ( ELITE )  
NAME OF LIGHT (1<sup>ST</sup> LETTER )

A ( AMBER )  
COLOR OF LIGHT



**6' OVAL**  
AMBER - OA  
CLEAR AMBER - OCA  
RED - OR  
CLEAR RED - OCR



**PETE**  
AMBER - PA  
CLEAR AMBER - PCA  
RED - PR  
CLEAR RED - PCR



**ELITE**  
AMBER - EA  
CLEAR AMBER - ECA  
RED - ER  
CLEAR RED - ECR



**ELITE MINI**  
AMBER - EMA  
CLEAR AMBER - EMCA  
RED - EMR  
CLEAR RED - EMCR



**TUNNEL LIGHT**  
AMBER - TA  
RED - TR



**2' ROUND**  
AMBER - RA  
CLEAR AMBER - RCA  
RED - RR  
CLEAR RED - RCR



**CORAL**  
AMBER - CA  
CLEAR AMBER - CCA  
RED - CR  
CLEAR RED - CCR



**MAGNUM**  
RED - MR



U



RN



S

