

CAB & SLEEPER PANELS



CAB PANELS
SLEEPER PANELS
HOOD REPLACEMENT PANELS
EXTENSION PANELS



CAB PANELS



VV112000
CAB PANELS - BLANK - NO
SIDE FAIRING

USE THE BLANK CAB PANELS FOR YOUR CAB PANEL LIGHT OPTIONS



EXAMPLE
VV112000-4EA

TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER**
- 2 - PICK LIGHT TYPE (REFER TO PAGE 211)**
- 3 - PICK THE NUMBER OF LIGHTS**

EXAMPLE: **VV112000 - CAB PANEL - BLANK**
 4 - NUMBER OF LIGHTS
 E - ELITE (A - AMBER)
 VV112000 - 4 EA



SLEEPER PANELS



VV143000

SLEEPER PANELS - BLANK -
WITH NO SIDE FAIRINGS

**USE THE BLANK SLEEPER PANELS FOR
YOUR SLEEPER PANEL LIGHT OPTIONS.**



EXAMPLE

VV143000 - 5 UN



EXAMPLE

VV143000- 5 RN



EXAMPLE

VV143000 - 7 RA



EXAMPLE

VV143000 - 5 TL



EXAMPLE

VV143000 - 4 EA

TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 211)
- 3 - PICK THE NUMBER OF LIGHTS

EXAMPLE:

VV143000 - 48" BLANK

4 - NUMBER OF LIGHTS

E - ELITE (A - AMBER)

VV143000 - 4 EA



HOOD EXTENSION PANELS



VV110300
HOOD EXTENSION PANEL
- BLANK

USE THE BLANK PANELS FOR YOUR EXTENSION PANEL LIGHT OPTIONS

EXAMPLE



VV110300-4EA

TO BUILD A PANEL

- 1 - PICK BLANK PART NUMBER
- 2 - PICK LIGHT TYPE (REFER TO PAGE 211)
- 3 - PICK THE NUMBER OF LIGHTS

EXAMPLE: **VV110300 - HOOD EXTENSION - BLANK**
 4 - NUMBER OF LIGHTS
E - ELITE (A - AMBER)
VV110300 - 4 EA